

BOSCH Disc Eco for Wood 230x30x24T



Cod produs:

2608644381

preturile contin TVA 19%

Caracteristici

Despre produs